

**Replacement Parts Listings for Oneida Oil-Fired Warm Air Furnace Models:**

- **LO-B-80R**
- **LO-B-120R**

## PARTS LISTING: LOWBOY MODEL: LO-B-80R & 120R

Ref. No.	Description	LO-B-80R	LO-B-120R
1	Left Side Panel Assembly	29631L	28423L
2	Right Side Panel Assembly	29630L	28422L
3	Upper Rear Panel	29638L	26048L
4	Blower Division Panel - 3 Ton	29637	29660
	Blower Division Panel – 5 Ton	N/A	29706
5	Base Panel Assembly	28459	28459
6	Inner Front Panel	29635	29683
7	Blower Access Door	27367L	26586L
	Door Handle – P2-41	28673	28673
8	Front Door Panel	29633R	29386R
	Logo Bezel	28479	28479
	Logo Label	29687	29687
9	Top Front Panel	26017L	26017L
10	Heat Exchanger Assembly	29619	29623
11	Firepot Bracket Assembly	4141185A	4141185A
12	Replacement Combustion Chamber	29673	29673
13	Rear Baffle	29157	29655
14	Left Side Panel Baffle	29158	29657
15	Right Side Panel Baffle	29159	29656
16	Oil Burner Mounting Plate Assembly	27033	27033
	Inspection Door Gasket RH	27040	27040
	Inspection Door Gasket LH	27041	27041
	Inspection Door Gasket Centre	27096	27096
17	Pouch Gasket	2080175	2080175
18	Clean-out Collar Gasket	29176	29176
19	Flue Pipe Collar	27476	20B146102
20	Clean-out Cover Gasket	29682	29682
21	Clean-out Cover	29663	29663
22	Air Filter – 20 x 20 x 1 (Permanent)	2180032	-----
	Air Filter – 20 x 25 x 1 (Permanent)	-----	2180024
23	Control Panel	29653	29653
24	Control Panel Cover	29654	29654
25	Wire Harness Blower Motor Direct Drive	29690	29690
	Wire Harness Blower Motor Belt Drive	29691	29691
26	Wire Harness Fan Timer Board	29751	29751
27	Wire Harness Transformer and Supply	29364	29364
29	Fan Timer Board ST9103A1002	29388	29388
30	Transformer, 4000-01V18BB2, 120/24v, 40 va	27738	27738
31	Limit Control 60T11 BOF (Black Oxide Finish)		
	80 mbtu/h Belt and Direct Drive (3 Ton Models)	29198 (L140°F)	
	120 mbtu/h Direct Drive (5 Ton Model)		28654 (L180°F)
	120 mbtu/h Belt and Direct Drive (3 Ton Models)		29662 (L160°F)
33	Draft Regulator	27494	12240

## PARTS LISTING: LOWBOY MODEL: LO-B-80R & 120R

Ref. No.	Description	LO-B-80R	LO-B-120R	
34	Beckett oil Burner	29596 (AF76BO)	29598 (AF76XN)	
	Burner Motor 1/7 HP 3450 RPM PSC	29689	29689	
	Beckett Cleancut Oil Pump	29688	29688	
	Solid State Ignitor	29522	29522	
	<hr/>			
	Primary Combustion Control R7184A	29664	29664	
	Air Tube Combination	28583	27610	
	Flame Retention Head	11960 (F0)	11961 (F3)	
	Nozzle	29641	29643	
		0.70 gph/70°W	1.00 gph/70°W	
34	Riello Oil Burner 40F3	29568	29567	
	Nozzle	27346	29642	
		0.65 gph/70°W	0.85 gph/70°W	
	<hr/>			
35	Blower Assembly, Complete, Direct Drive, ½ hp, 4-Speed	29668	29670	
	Blower Housing and Wheel, GT-10 DD Special	15010	-----	
	Blower Housing and Wheel, G-10 DD	-----	15011	
	Blower Wheel, GT-10 DD & G-10 DD	26430	26430	
	<hr/>			
	Blower Motor, ½ hp, 4-Speed	26088	26088	
	Motor Mounting Band – TR6884B	17811	17811	
	Motor Mount Arms – 10-10 DD Blower (3 per unit)	26251	26251	
	Motor Run Capacitor, 10 mfd @ 370 vac	27743	27743	
	<hr/>			
	Capacitor Strap	27760	27760	
	Capacitor Insulator	27769	27769	
	Blower Base Feet LH	29703	29703	
Blower Base Feet RH	29704	29704		
<hr/>				
35	Blower Assembly, Complete, Belt Drive, ½ hp	29669	29671	
	Blower Housing and Wheel, GT-10 Special	17996	-----	
	Blower Housing and Wheel, G-10	-----	10361	
	Blower Wheel, GT-10 & G-10	26430	26430	
	Blower Motor, ½ hp	29609	29609	
	<hr/>			
	Adjustable Motor Pulley 3 ¼" x ½"	2240001	2240001	
	Blower Pulley 5" x ¾"	2240005	2240005	
	Blower Belt 35"	2240065		
	Blower Base Feet LH	28643	28643	
Blower Base Feet RH	28642	28642		
<hr/>				
35	Blower Assembly, Complete, Direct Drive, ¾ hp		29672	
	Blower Housing and Wheel, GT 12-10 DD	-----	17559	
	Blower Wheel, GT 12-10 DD		29692	
	Blower Motor, ¾ hp 4 Speed	-----	27161	
	Motor Mounting Band – TR6884B	-----	17811	
	<hr/>			
	Motor Mount Arms – 12-12 DD Blower (3 per unit)	-----	17812	
	Motor Run Capacitor, 20 mfd @ 370 vac	-----	27745	
	Capacitor Strap	-----	27761	
	Capacitor Insulator	-----	27768	
	<hr/>			
Blower Base Feet LH	-----	29703		
Blower Base Feet RH	-----	29704		

# MODEL LO-B-80R & 120R DIAGRAM

